

Spring Pretensioning Chart for Awning Spring Awnings

This chart may be used as a guide for the amount of tension required, expressed as the number of turns needed.

DROP	WIDTH											
	600	900	1200	1500	1800	2100	2400	2700	3000	3300	3600	3900
300	5	8	8	9	9	10	10	10	10	10	10	10
600	5	8	8	9	9	10	10	10	10	10	10	10
1200	5	10	10	10	10	11	11	11	11	11	11	11
1500	5	11	11	11	11	11	11	11	11	11	11	11
1800	5	12	12	12	12	12	12	12	12	12	12	12
2100	5	13	13	13	12	13	13	13	13	13	13	13
2400	5	5	7	13	13	13	13	13	13	13	13	13
2700	5	5	7	14	14	14	14	15	15	15	15	15
3000	5	5	8	14	14	14	14	15	15	15	15	15

Notes

Figures in this chart are a guide only

DO NOT over tension

Use only enough tension to give a smooth operation in the Awning

Figures are for awnings manufactured in canvas fabric only but can be used as a rough guide for other fabrics