

INSTALLATION GUIDE

ROMAN BATTERY-OPERATED BLIND

Please Note: These instructions should be read thoroughly before installing.

This is a guide to assist in the installation and care of your blinds. Betta Blinds & Awnings does not guarantee the accuracy of the information contained in this guide. We recommend an experienced expert installer to rely upon their own skills. This is based on general knowledge concerning the assembly, materials and working process of the blinds, which is known to us at the time of printing this guide, consequently, is subject to change and Betta Blinds & Awnings specifically reserves the right to change this guide without notification.

We recommend the use of the following Tools: Steel measuring tape, Carpenter's level, Power or battery drill & bits, Flat blade and Phillips head screwdrivers

The following should be included for each Roman Blind ordered:

- ☉ Installation brackets
- ☉ (number of brackets is based on 200mm from each end plus 1 bracket per 800mm based on track width)
- ☉ Installation gloves

When installing and handling fabric blinds, clean soft cotton gloves (or soft vinyl gloves supplied) must be worn to avoid marking the fabrics.

Since different screws are required to suit different fixing applications, we do not supply screws. Please ensure you use the correct screws for mounting to the desired application, for example Gyprock, timber, concrete, brick, steel or aluminium.

The most important procedure in installing these blinds is to be sure that the correct anchorage method has been used so that the mounting area (i.e. wall or architrave) is able to support the weight of the blind and its operation.

- ☉ **Brick or Rendered Surfaces Warning:** Make sure drilling is no closer than 25mm from edge of surfaces as the brick or render may chip or break out.


☉ INSTALLATION

1. Check the marked width and drop sizes as indicated on the packaging against your original order.
2. Each blind is marked to indicate the room location, as per your order form, to assist in establishing the correct fitting location of multiple blind orders.
3. If all is correct layout the blinds at their location and remove protective packaging.
4. Remove the supplied installation brackets from their packaging.
5. Since different screws are required to suit different fixing applications, we do not supply screws. Please ensure you use the correct screws for mounting to the desired application, for example Gyprock, timber, concrete, brick, steel or aluminium
6. **The most important procedure in installing these blinds is to be sure that the correct anchorage method has been used so that the mounting area (i.e. wall or architrave) is able to support the weight of the blind and its operation.**
7. Ensure the blind has brackets to suit the application, either face fix or reveal.
8. Level mounting is critical to the correct operation of the blind (use a spirit level).
9. Fix the required brackets in the necessary positions of equal spacing to accommodate load bearing distribution. (200mm from each end plus 1 bracket per 800mm based on track width)
10. Betta Blinds supplies mounting brackets only, and where appropriate the child safety devices.


INSTALLATION - LOW PROFILE MOUNTING CLIPS

STEP 5. - ATTACH HEAD RAIL TO MOUNTING CLIPS


Mount the shade assembly onto the Mounting Clips.



NOTE: Top Fix shown as example. Also applies to Face Fix.



STEP 6. - ATTACH HEAD RAIL TO MOUNTING CLIPS (COMPLETE)



11. Once the brackets have been installed and levels checked the blind is ready to be installed into the brackets as above photo shows

Note: The top and bottom limits have already been set so no programming is necessary. If more than one blind is ordered the remote has been programmed as per the way the order is sent to us, e.g., channel 1 is the first blind on the order Channel 2 is the second blind on the order. Instructions for programming are in the remote box if needed. The 5 and 15 channel remotes come locked so will need to be unlocked if limits need to be changed.

12. After installing the blind, operate the blind up and down twice, this will settle the blind after transporting. Check the mechanism's operation and also make sure the fabric is not rubbing against any obstacles. This can damage the blind if left untreated.
13. It is important when using this blind that it is operated **carefully** to prolong the life of the product and maintain the warranty period.
14. **Please note:** *If the blind has rear aluminium battens the fabric may appear to hang shorter than required after first installing. However, these battens allow for the fabric to drop after a few days. This factor has been taken into consideration when the blinds were manufactured. Please see settling time note below.*

NOTE: Video Link: How to Steam a Roman Blind: <https://www.loom.com/share/5bddf4039b4e4629963d30a1ef474f3b>

PLEASE NOTE: SETTLING TIME: All Roman Blinds and Panel Glides with Aluminium Battens settle out after installation. The weight of the fabric, size of the blind and environmental factors all effects the extent to which a blind will settle. As this process is somewhat unpredictable the final drop of the blind may vary by up to +/- 10mm. Blinds may take 4-8 weeks of hanging to allow fabric to drop to the required length. Blinds can drop up to 20-40mm after hanging.

● Maintenance and cleaning

Regularly remove surface dust gently with a clean dry soft cloth, feather duster or soft brush or wipe with a dry sponge. Recommended cleaning agent is mild detergent in lukewarm water. Stains and smudges can be removed with lukewarm water and neutral soap on a sponge. The sponge should be squeezed almost dry. Fabric may be sponged but severe rubbing should be avoided. White spirits may be used for spot cleaning; methylated spirits (ethanol) and dry-cleaning solvent (Perc) must not be used. If commercial spot cleaners are used, then instructions regarding testing of an inconspicuous area should be followed. For any cleaners used, first test and allow to dry on an inconspicuous area to ensure compatibility. For removing small marks an art gum eraser can be used with light rubbing.

Please note that all fabrics fade from UV exposure. If blinds are left up for a long time without being pulled down regularly, all fabrics will fade unevenly. Fabric will fade evenly if blinds are down during the day, getting even UV exposure. When fading occurs in that instance, it is even across the entire fabric and is not noticeable.

Professional ultrasonic cleaning can be undertaken by specialist cleaning businesses.

● Warranty

Betta Blinds guarantee the quality on all our specified fabrics free from defects for one (1) year from date of purchase. All fabrics manufactured by Betta Blinds are cut using Ultrasonic or Aeronaut Fabric Cutting Technology, this is essential for cutting square and to aid the elimination of fabric fray. Due to this technology, we can guarantee our fabrics against fault of manufacture. Betta Blinds guarantee the quality on all our blind components free from defects and/or failure for five (5) years from the date of purchase.

The guarantee on Betta Blinds products does not cover defects or damage caused by accidents, alterations, misuse, abuse, wear and tear or failure to comply with cleaning and maintenance instructions. Betta Blinds does not warranty the fading of fabrics and timbers caused by direct and/or indirect sunlight. Under the guarantee Betta Blinds shall not be liable or responsible for incidental or consequential damages or any other direct or indirect damage, loss, cost, expense or fee. Acmeda Roman Motors & Wi-Fi Hub come with a 7-year warranty. Acmeda remotes have a 5-year warranty.

WARNING:

CURTAIN AND BLIND CORDS HAVE CAUSED THE DEATH OF YOUNG CHILDREN AND MUST BE INSTALLED SO THAT THEY ARE NOT A STRANGULATION HAZARD. FOLLOW THE INSTALLATION INSTRUCTIONS

Keep children away from all cords/chains.

Move anything a young child can sit in, stand in or climb on (like cots, highchairs, beds, sofas, tables, chairs and bookshelves) away from cords/chains—even those tied around a cleat, as your child may be able to untie them.

Do not let your child play near cords/chains they can easily reach. Never leave your child alone in a room with cords/chains they can reach.



CHILDREN'S SAFETY REGULATIONS:

- ♦ To avoid creating a possible strangulation hazard for children, the corded internal window covering must be installed in such a way that a loose cord cannot form a loop 220mm or longer at a height of less than 1,600mm above floor level.
- ♦ No part of a cord guide may be installed lower than 1,600mm above floor level unless, the cord guide will remain firmly attached to a wall or structure specified in the installation instructions when subjected to tension force of 70 N applied in any direction for 10 seconds and the cord is sufficiently secured or tensioned to prevent the formation of a loop 200mm or longer.
- ♦ If a cord guide is installed lower than 1,600 above floor level it must be designed to prevent a child from being able to remove the cord.
- ♦ If a cleat is used to secure the cord it must be at least 1,600mm above floor level because a child is capable of unwinding a cord from a cleat.
- ♦ **The person installing a corded internal window covering must attach a label to the corded window covering containing the name and contact details of the person or company responsible for the installation.**
- ♦ **They also must ensure that any warning label or swing tag supplied with the corded window covering remains attached to the cord.**

CHILDREN'S SAFETY REGULATIONS:

- ♦ To avoid creating a possible strangulation hazard for children, the corded internal window covering must be installed in such a way that a loose cord cannot form a loop 220mm or longer at a height of less than 1,600mm above floor level.
- ♦ A cord guide may be installed lower than 1,600mm above floor level if the cord is sufficiently secured or tensioned to prevent a loop.
- ♦ If a cord guide is installed lower than 1,600 above floor level it must be designed to prevent a child from being able to remove the cord.
- ♦ If a cleat is used to secure the cord it must be at least 1,600mm above floor level because a child is capable of unwinding a cord from a cleat.
- ♦ A label must be attached to the corded window covering *containing the name and the contact details of the company or person responsible for the installation.*
- ♦ You also must ensure that any warning label or swing tag supplied with the corded window covering remains attached to the cord.